

Réf. 055148

TBP 500

BATTERY TESTER

12V

For lead-acid batteries until 160 Ah

Functions :

Test the starting capacity of the battery

Indicates the state (good or bad) of the battery

Test the charge level of the battery

Test the alternator voltage. It detects if there is a problem in the load circuit of the vehicle which can damaged the battery or the electronic on board.



Made in PRC

Dimensions in cm : 27 x 26 x 13

Weight : 8 kgs

