





Model No: FS4000

Parts List

ID	Part No	Name	Qty	Notes
1	158875-2	LOCATOR S COMPLETE	1	
2	424163-2	DUST SEAL SLEEVE	1	
3	424235-3	SEAL RING 30	1	
4	450881-6	LOCK RING	1	
5	233974-2	RING SPRING 33	1	
6	232245-4	LEAF SPRING	1	
7	266361-0	TAPPING SCREW 4X30	3	
8	158883-3	GEAR HOUSING HP COMPLETE	1	
9	232050-9	LEAF SPRING	1	
10	216001-0	STEEL BALL 3.5	1	
11	324983-3	SPINDLE 125N	1	
16	233126-5	COMPRESSION SPRING 6	1	
17	268229-6	COLLARED PIN 8	1	
18	***	***	***	Click for Technical Bulletin 96622
19	216415-3	THRUST NEEDLE GAUGE 821	1	
20	216212-7	WASHER 821	1	
21	424162-4	SEAL RING	1	
22	158874-4	GEAR HOUSING COVER COMPLETE	1	
23	451099-2	RING 7	1	
24	210007-0	BALL BEARING 608VV	1	
25	240083-0	FAN 52	1	
26	515759-1	ARMATURE ASSEMBLY 240V	1	
27	681636-0	INSULATION WASHER	1	
28	210062-2	BALL BEARING 607ZZ	1	
29	421868-5	LABYRINTH RUBBER RING 19	1	
30	266467-4	TAPPING SCREW 4X50	2	
31	450880-8	BAFFLE PLATE	1	
32	633693-4	FIELD 220-240V	1	
33	450885-8	MOTOR HOUSING L2	1	
34	162272-6	HOOK	1	
35	866602-0	FS4000 NAME PLATE	1	
36	808575-1	4000RPM INDICATION LABEL	1	
37	689111-0	SPACER	2	
38	195015-1	CARBON BRUSH CB-419	1	
39	643948-9	BRUSH HOLDER	1	
40	643951-0	BRUSH HOLDER	1	
41	687140-7	STRAIN RELIEF	1	
42	650614-1	SWITCH	1	
43	158878-6	HANDLE COVER L COMPLETE	1	
44	266374-1	TAPPING SCREW 4X25	1	
45	266374-1	TAPPING SCREW 4X25	2	
47	646122-8	CHOKE COIL	1	
48	645253-0	NOISE SUPPRESSOR	1	
49	265995-6	TAPPING SCREW 4X18	2	
50	682566-8	CORD GUARD 10	1	
51	666415-7	POWER SUPPLY CORD 1.0-2-2.0	1	



Model No: FS4000

ID	Part No	Name	Qty	Notes
52	***	***	***	Click for Technical Bulletin 90203
53	423413-2	RUBBER PLATE	1	
1001	784261-7	+BIT 2-25	2	
1002	784811-8	MAGNETIC CONNECT BIT 6.35-60	1	

toolsparts.com.au