





Parts Breakdown

HR2400

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
3	134715-8	GRIP ASS'Y, HR2400	1
4	931302-2	HEX NUT M6, HR2400	1
5	150822-9	GEAR HOUSING COMPLETE, HR2400-T2	1
	159594-3	GEAR HOUSING, HR2400-T1	
6	911273-9	P.H. SCREW M5X50, HR2400	4
7	213720-9	O RING 67, HR2400	1
11	211323-3	BALL BEARING 6904LLU, HR2420	1
12	213418-8	OIL SEAL 28, HR2400	1
13	231954-2	RING SPRING 28, HR2400	1
14	267110-8	FLAT WASHER 31, HR2400	1
15	233060-9	COMPRESSION SPRING 31, HR2400	1
16	226260-8	SPUR GEAR, HR2400	1
19	323725-2	TOOL HOLDER, HR2400-T2	1
	322553-2	TOOL HOLDER, HR2400, T1	
	134813-8	TOOL HOLDER ASS'Y, HR160D	
	134714-0	TOOL HOLDER ASS'Y	
20	267105-1	FLAT WASHER 29, HR2811F	2
21	213063-9	O RING 10, HR2400	1
23	323723-6	IMPACT BOLT, HR2400-T2	1
	322586-7	IMPACT BOLT, HR2400, T1	
24	321915-1	IDLER, HR2400	1
25	262038-5	RUBBER RING 17, HR2400	1
26	857141-1	NAME PLATE, HR2400	1
27	415415-2	MOTOR HOUSING, HR2400	1
28	911581-8	PAN HEAD SCREW M4X55, 6820V	2
29	212040-8	T. N. BEARING 819, HR2400	1
30	226421-0	HELICAL GEAR 31, HR2400	1
	226410-5	HELICAL GEAR 31, HR2400	
31	219007-7	SWASH BEARING 9, HR2400	1
	219004-3	SWASH BEARING 9, HR2400	
32	322588-3	CAM SHAFT, HR2400	1
33	322652-0	CLUTCH, HR2400	1
34	226259-3	SPUR GEAR 10, HR2400	1
35	415372-4	CHANGE LEVER, HR2400	1
36	213265-7	O RING 17, HR4002	1
38	251392-2	PAN HEAD SCREW M4, HR2400	1
39	265715-8	SCREW 6X40, HR2400	1
40	267104-3	FLAT WASHER 12, HR2400	1
41	321916-9	PISTON JOINT, HR2400	1
42	267104-3	FLAT WASHER 12, HR2400	1
43	267109-3	FLAT WASHER 13.5, HR2400	1
44	231953-4	RING SPRING, HR2400	1
45	322587-5	STRIKER, HR2400	1
46	213214-4	O RING 16, HR2400	1
47	316450-2	PISTON CYLINDER, HR2400	1
48	159653-3	GEAR HOUSING COVER, HR2400	1
49	213385-7	O RING 24, HR2400	1
50	211051-0	BALL BEARING 609LLB HR2400	1
51	213112-2	OIL SEAL 12, HR2400	1
52	241850-6	FAN 60, BTW450	1
53	515161-8	ARMATURE ASS'Y 115V, HR2400	1
54	681625-5	INS. WASHER, 5007F	1
55	211031-6	BALL BEARING 608LLB, 9227C	1
56	253192-6	F. WASHER 14, LXSFO1	1
57	415127-7	BAFFLE PLATE, HR2400	1
58	625156-4	FIELD 115V, HR2400	1
59	231457-6	COMP. SPRING 3, HR2400	1
60	CB416	CARBON BRUSH SET, 195013-5	1



Parts Breakdown

HR2400

	195013-5	CARBON BRUSH SET, 195013-5	
	191954-3	CARBON BRUSH SET CB416, HR2400	
61	651918-4	SWITCH, HR2400	1
62	415117-0	LOCK PLATE, HR2400	1
63	415120-1	SWITCH LEVER, HR2400	1
64	415118-8	LOCK BUTTON, HR2400	1
65	263002-9	RUBBER PIN 4, 5007MG	2
66	152416-6	HANDLE COVER, HR2400	1
67	265995-6	TAPPING SCREW 4X18, BO4556K	4
68	421460-7	DUST COVER, HR2400	1
69	651556-2	SWITCH, 6905H	1
70	265995-6	TAPPING SCREW 4X18, BO4556K	2
71	687063-9	STRAIN RELIEF, 4323K	1
72	664064-4	CORD (2X18X8 SJ), BO4556	1
73	682502-4	CORD GUARD 8-85, HP2010N	1
76	231288-3	COMP. SPRING 6, HR2400	1
77	322653-8	PUSH CONE, HR2400	1
78	256447-8	PIN 8, HR2420	1
	322517-6	ROLLER 7, HR2400	
79	323724-4	CHUCK RING, HR2400	1
	154404-9	CHANGE RING, HR2400 (T3)	
80	286265-0	CAP 31, HR2400,T2	1
	286248-0	CAP 31, HR2400 T1	
	286234-1	CAP 37, HR2000,T2, HR2400	
81	232192-9	LEAF SPRING 26, HR2400	1
	232190-3	LEAF SPRING 26, HR2410	
	232177-5	LEAF SPRING	
82	344574-4	SPRING GUIDE, HR2400	1
83	416410-5	CHUCK COVER, HR2400	1
	415076-8	CHANGE RING COVER, HR2400	
84	233203-3	COMPRESSION SPRING 38, HR2400	1
	213068-9	O RING 10, HR2400	
85	233202-5	COMPRESSION SPRING 20, HR2400	1
86	216022-2	STEEL BALL 7.0, HR2400	1
	216009-4	STEEL BALL 7.1, HR2400	
87	231979-6	RING SPRING 16, HR2400	1
	257172-4	RING 20, HR2400	
	321144-6	STOPPER POLE, HR2400	1
	824445-6	PLASTIC TOOL CASE, HR2400	
	824608-4	PLASTIC TOOL CASE HP2010N	
	824445-6	PLASTIC TOOL CASE, HR2400	
	182617-2	STEEL CARRYING CASE, HP2010N	