







## Parts Breakdown

LS1214

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	265995-6	TAPPING SCREW 4X18, BO4556K	2
2	416075-3	REAR COVER, LS1013	1
3	265995-6	TAPPING SCREW 4X18, BO4556K	1
4	631237-4	CONTROLLER, LS1214FL	1
6	911373-5	P.H. SCREW M6X50, LS1013	4
7	153907-0	MOTOR HOUSING CPL., LS1214	1
8	CB154	CARBON BRUSH SET, 194986-9	1
	194986-9	CARBON BRUSH SET, 194986-9	
	181047-4	CARBON BRUSH SET 154,5402A	
9	643650-4	BRUSH HOLDER CAP, 5007F	2
10	860629-2	NAME PLATE, LS1214	1
11	596156-0	FIELD ASS'Y 115V, LS1212	1
12	266059-9	T. SCREW, FLANGE 5X75,2414B	2
13	416264-0	BAFFLE PLATE, LS1212	1
14	211061-7	B. BEARING 6000LLB, 6222DWE	1
15	681642-5	INSULATION WASHER, LS1016L	1
16	516736-6	ARMATURE ASS'Y 115V, LS1212	1
17	240001-8	FAN 80, LS1016L	1
18	911223-4	P.H. SCREW M5X16, 5007MG	2
19	285686-3	BEARING RETAINER 94, LS1214FL	1
20	210301-0	BALL BEARING 6003DDW, RT0700C	1
	211275-8	BALL BEARING 6003DDW, 9741	
21	961057-5	RETAINING RING S-17, LS1016L	1
22	231928-3	RING SPRING 8, LS1016L	1
23	256633-1	PIN 6, LS1016L	1
24	231240-1	COMP. SPRING 7, LS1016L	1
25	961018-5	STOP RING E-5, LS1016L	1
26	253804-1	F. WASHER 6, LS1016L	1
27	257163-5	RING 6, LS1016L	1
28	345419-9	LINK PLATE, LS1214	1
29	922331-6	H.S.H. BOLT M6X20, LS1016L	1
30	253804-1	F. WASHER 6, LS1016L	1
31	257163-5	RING 6, LS1016L	1
32	316470-6	SPRING HOLDER, LS1211	1
33	233187-5	COMPRESSION SPRING 34, LS1212	1
47	411478-6	SWITCH BUTTON, LS1011	1
48	182910-4	HANDLE SET, LS1013	1
49	682505-8	CORD GUARD, 5007F	1
50	664463-0	CORD (2X14X8 SJ), 5007F	1
51	687052-4	STRAIN RELIEF, 5007F	1
52	265995-6	TAPPING SCREW 4X18, BO4556K	2
53	414546-4	CAM, LS1011	1
54	416000-4	LOCK OFF LEVER, LS1040	1
56	231457-6	COMP. SPRING 3, HR2400	1
58	651923-1	SWITCH, LS1040	1
60	415999-0	SWITCH LEVER, LS1040	1
61	265995-6	TAPPING SCREW 4X18, BO4556K	6
62	182910-4	HANDLE SET, LS1013	1
63	921467-8	HEX BOLT M8X45, LS1013	1
64	262003-4	RUBBER RING 6, LS1013	1
65	911323-0	P.H. SCREW M6X16, LS1211	1
66	421562-9	GRIP, LS1013	1
67	344420-1	GRIP HOLDER, LS1013	1
68	911323-0	P.H. SCREW M6X16, LS1211	1
69	911114-9	P.H. SCREW M4X10, LS1013FL	1
70	419277-0	DUST NOZZLE, LS1016L	1
	416133-5	DUST NOZZLE, LS1013	
71	213460-9	O RING 35, LS1016L	1



## Parts Breakdown

LS1214

72	911113-1	P.H. SCREW M4X10, LS1016L	1
73	265717-4	SCREW M6X43, LS1016L	1
74	262001-8	RING 5, LS1016L	1
75	317176-9	STOPPER ARM, LS1212	1
76	344045-1	STOPPER ARM PLATE, LS1211	1
77	819215-6 819064-1	MAKITA LOGO LABEL, LS1214L MAKITA MARK, 5402NA	1
78	188379-0 183896-5	BLADE CASE SET, LS1214F BLADE CASE, LS1214	1
79	345611-7 345415-7	GUARD PLATE, LS1214L GUARD PLATE, LS1214	1
80	421916-0 423332-2	GUARD, LS1013L GUARD, LS1214	1
81	211031-6	BALL BEARING 608LLB, 9227C	1
82	961054-1	RETAINING RING S-14, 6302	1
83	226750-1	SPIRAL BEVEL GEAR 35, LS1214FL	1
84	262074-1	RUBBER RING 20, LS1013	1
85	267035-6	F. WASHER 14, LS1214F	1
86	213675-8	O RING 54, LS1214	1
87	316473-0	HOUSING W/O BEARING, LS1211	1
88	254202-2	KEY 4, 9924DB	1
89	322989-5	SPINDLE, LS1212	1
90	211278-2	BALL BEARING 6203DDW, GA7021	1
91	285828-9	BEARING RETAINER 66, LS1211	1
92	257022-3	RING 16, LS1013	1
93	911223-4	P.H. SCREW M5X16, 5007MG	2
94	224333-1	FLANGE 53, LS1040	1
95	257060-5	RING 15.88,LS1013	1
96	224333-1	FLANGE 53, LS1040	1
97	265405-3	H.F.H. BOLT M10X20, LS1016L	1
98	344473-0	CENTER PLATE, LS1212	1
99	344038-8	CENTER COVER, LS1211	1
100	265324-3	H.F.H. BOLT M8X12, LS1016L	1
101	265008-3	.SCREW M5, LS1011	1
102	231613-8	T. SPRING 45, LS1211	1
103	450131-9 418614-5	SAFETY COVER, LS1214F SAFETY COVER, LS1214	1
104	253977-0	F. WASHER 6, LS1011	1
105	911213-7	P.H. SCREW M5X12, LS1040	1
106	331428-4	PIPE, 2414NB	1
107	252105-4	HEX LOCK NUT M8-13, LS1040	1
108	941201-0	F. WASHER 8, 5007NK	1
109	154780-1 153908-8	ARM CPL., LS1214L ARM CPL., LS1214	1
110	322988-7	STOPPER PIN, LS1220	1
111	213011-8	O RING 7, HR2511,LS1214FL	1
112	687095-6	STRAIN RELIEF, LS1016L	1
113	266026-4	TAPPING SCREW 4X12, LS1016L	1
115	251961-9	H.S.H. SCREW M6X10, LS1040	1
116	265371-4	HEX BOLT M8X30, LS1011	2
117	265412-6	HEX. BOLT M8X20, LS1013	2
118	216003-6	STEEL BALL 10, 2401B, LS1013	2
119	345418-1	GUIDE PLATE, LS1013	1
120	231626-9	TORSION SPRING 28, LS1013	1
121	413067-3	INDICATION PLATE, LS1013	2
122	911114-9	P.H. SCREW M4X10, LS1013FL	2
123	233168-9	COMPRESSION SPRING 5, LS1013	2
124	266131-7	HEX SOCKET HEAD BOLT M12X12, LS1013	2
125	151459-5	ARM HOLDER COMPLETE, LS1013	1
126	251662-9	H. BOLT M10X100, 2030N	1
127	911113-1	P.H. SCREW M4X10, LS1016L	1



## Parts Breakdown

LS1214

128	416006-2	LEVER 100, LS1040	1
129	252144-4	HEX. NUT M10-17, LXSL01	1
130	253024-7	F. WASHER 10, LS1016L	1
131	231266-3	COMP. SPRING 5, LXSL01	1
132	152542-1	SQUARE ROD COMPLETE, LS1013	1
133	921356-7	HEX BOLT M6X35, LS1013	2
134	153832-5	TURN BASE CPLT., LS1013	1
135	152540-5	BEARING BOX B COMPLETE, LS1013FL	1
136	922451-6	H.S.H. BOLT M8X30, JS3200	2
137	253852-0	F. WASHER 8, LS1211	1
138	265442-7	HEX BOLT M8X40, LS1013	1
139	415209-5	KERF BOARD, LS1013,LS1013F	2
140	266026-4	TAPPING SCREW 4X12, LS1016L	4
141	911108-4	P.H. SCREW M4X8, LS1013	1
142	252014-7	HEX LOCK NUT M6-10, LS1040	1
143	344463-3	SUB FENCE PLATE, LS1013	1
144	153892-7	SUB-FENCE CPL., LS1214	1
145	921451-3	HEX BOLT M8X30, LS1011	4
146	317757-9	GUIDE FENCE, LS1214	1
147	912357-6	C.S.H. SCREW M6X35, LS1013	1
148	253715-0	F. WASHER 6, NHP1310	1
149	251887-5	SCREW M6X10, LS1016L	1
150	266026-4	TAPPING SCREW 4X12, LS1016L	2
151	816326-8	MITER SCALE PLATE, LS1013	1
152	266132-5	SCREW M8X320, LS1013FL	1
153	931402-8	HEX NUT M8, 5037NB	1
154	271314-6	KNOB 40, LS1212	1
155	941201-0	F. WASHER 8, 5007NK	1
156	152541-3	KNOB 48 COMPLETE, LS1013	1
158	331491-7	PIPE 9-200, LS1013FL	1
159	421563-7	CAP 10, LS1013	1
160	322924-3	COIL SPRING, LS1013FL	1
161	322909-9	LOCK PIN, LS1013	1
162	253804-1	F. WASHER 6, LS1016L	1
163	231307-5	COMP. SPRING 6, LS1013	1
164	961018-5	STOP RING E-5, LS1016L	1
165	316899-6	PIN HOLDER, LS1013	1
166	266034-5	TAPPING SCREW 4X16, LS1016L	2
167	344411-2	SLIDE STOPPER, LS1013	1
168	251267-5	P.H. SCREW M6, LS1016L	1
169	256196-7	PIN 5, LS1013	1
170	331493-3	TURN STOPPER, LS1013FL	1
171	344412-0	STOPPER HOLDER, LS1013	1
172	266034-5	TAPPING SCREW 4X16, LS1016L	1
173	266026-4	TAPPING SCREW 4X12, LS1016L	1
174	816128-2	POINTER, LS1013	1
175	344477-2	SLIDE PLATE, LS1013	2
176	266034-5	TAPPING SCREW 4X16, LS1016L	1
177	232075-3	LEAF SPRING, LS1016L	1
178	251887-5	SCREW M6X10, LS1016L	2
179	153833-3	BASE CPL., LS1013	1
180	286212-1	CAP 20, 2705	4
	122523-9	DUST BAG, LS1040	1
	122540-9	VICE ASS'Y, LS1212	1
	153898-5	SUB-FENCE R CPL., LS1214	1
	411478-6	SWITCH BUTTON, LS1011	2
	762001-3	TRIANGLE RULE, LS1016L	1
	251887-5	SCREW M6X10, LS1016L	2
	322932-4	HOLDER 255, LS1013FL, LS1214FL	2
	A-94443	12X70T Q.MAKBLADE,LS1214F	1
	A-85472	T.C.T. SAW BLADE 60T	



## Parts Breakdown

**LS1214**

782232-8	BOX WRENCH 13, LS1016	1
782212-4	SOCKET WRENCH 13, LS1011	
941202-8	F. WASHER 8, BPB180	4
810151-9	N/A	1