



## Parts List for DCD980L2 Type 1

Item Number	Part Number	Description	Qty Required
5	N078823	WARNING LABEL (SPA)	1
14	N042665	MACHINE SCREW	1
15	N169778	BELT HOOK	1
20	586200-10	KEYLESS CHUCK	1
21	605256-01	SCREW	1
22	652378-00	RETAINING PLATE	1
23	650470-00	LOCK RING	1
24	652379-00	ANVIL	1
25	654110-00	PIN	5
26	N017098SV	GEAR ASS'Y.	1
27	N038862	COMPRESSION SPRING	1
28	650444-00	RING GEAR	1
29	N017099SV	GEAR ASSY.	1
30	N030490SV	GEAR ASSY.	1
31	657453-00SV	SHIFTER ASSEMBLY	1
32	654927-00SV	BAFFLE ASSEMBLY	1
42	N043352SV	CLAMSHELL,SET	1
43	N089938	SWITCH KIT	1
44	N031214SV	BRUSH BOX SET	1
45	N023147SV	ARMATURE ASSEMBLY	1
46	648124-00	MAGNET RING	1
47	N007948	BEARING CAP	2
48	N091392	F/R BUTTON	1
49	N031214SV	BRUSH BOX SET	1
51	N091729	IDENT. LABEL	1
52	682211-00	SCREW,TORX	13
53	330019-52	SCREW PLASTITE	4

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DCD980L2 Type 1

Item Number	Part Number	Description	Qty Required
54	N014681	DETENT SPRING	2
56	650421-00	SIDE HANDLE	1
61	N083460SV	GEARCASE ASSY	1
70	N088459	NAMEPLATE	1
800	N017298	GREASE	1
836	559662-99	MANDREL	1
836	596004-99	INSERT	1
836	233947-00	HOLDING FIXTURE	1
836	233804-40	CHUCK REMOVAL FIXTURE	1
861	N082200	KITBOX	1
866	DCB200	BATTERY PACK	2
871	DCB101	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.