



Parts List for DCS355B Type 1

ItemNumber	PartNumber	Description	QtyRequired
1	N232916	HOUSINGASSEMBLY	1
2	N341719	GEARCASEASSY	1
3	N341720	MOTOR&SWITCHASSY.	1
4	N233819	LEDASSY	1
6	N368300	TRIGGERASSEMBLY	1
7	N254620	CLAMPLEVER	1
8	N163918	LOCK-ONBUTTON	1
9	N165498	SPRING	1
10	330019-03	SCREW,PLASTITE	11
11	330045-43	SCREW,TAPTITE	2
12	N140357	TORSIONSPRING	1
13	N175484	SCREW	1
14	N243985	ELASTICSTOPNUT	1
15	N238819	RUBBERBUMPER	1
16	N239159	RUBBERBUMPER	1
17	N239160	RUBBERBUMPER	1
18	N241039	RUBBERBUMPER	2
19	N266442	RUBBERBUMPER	2
22	N328739	RUBBERBUMPER	2
23	N328740	RUBBERBUMPER	1
24	N328741	RUBBERBUMPER	2
41	N275350	BLOCKASSY.	1
42	N275341	DEPTHGUIDE	1
43	N278801	KNOB	1
44	891903	HEXWRENCH2.5MM	1
50	90587554	FLANGEASSY.	1
51	90583886	OUTERFLANGE	1

Parts List for DCS355B Type 1

ItemNumber	PartNumber	Description	QtyRequired
52	90583887	SCREW	1
53	90583888	O-RING	1
54	N440293	INNERFLANGE	1
55	90584745	WRENCH	1
75	N325100	RATINGLABEL	1
76	N238179	WARNINGLABEL	1
200	N276779	BLADEBOX	1
201	N364479	PLATEN	1
800	870889-03	GREASE	1
856	N283301	SANDPAPERPACK	1
856	DWA4203	BLADE	1
856	DWA4206	BLADE	1
862	629053-00	TOOLBAG	1
866	DCB203	BATTERYPACK	1
871	DCB115	CHARGER	1