

PartsList DC721K CORDLESSDRILL 10

Item	PartNumber	Qty	PartDescription	GeneralDescription	OtherInfo	RepairInst	Markets
1	645373-00	1	CLAMP No				
2	1007801-00	1	BRUSH&PLATE	No			
3	1007802-00	1	ARMATURESA 18vFRMLS.	No			
4	1007805-00	1	MAGNETSA	No			
5	632733-00	1	ADAPTOR	No			
6	656309-00	1	SLIDER No				
7	391896-00	1	SPRINGCLIP	No			
8	000000-00	1	NOLONGERAVAILABLE	No			
9	330075-61	1	CHUCK13MM Keyless	No			
10	605256-02	1	SCREW 1/4-28UNF(LH)T20	No			
12	N110357	1	BEARING			No	
20	000000-00	1	NOLONGERAVAILABLE	No			
21	N076359	1	SWITCHSA IncLED	No			
22	642891-00	1	REVERSER	No			
34	1007818-00	1	SPINDLESA			No	
36	N007449	1	COLLAR	No			
37	N053847	1	CAP	No			
38	682211-00	12	SCREW	No			
40	148354-03	1	HOLDER	No			
41	297757-02	1	BITPHILLIPS	No			
51	645221-00	1	CAP			No	
817	650190-00	1	IDENTITYLABEL			No	
821	000000-00	1	NOLONGERAVAILABLE			No	QW
861	392088-01	1	KITBOX			No	
866	000000-00	1	NOLONGERAVAILABLE		DC721KA	No	QW
866	1006628-00	1	BATTERY18V-2.6AH	NiMH-DE9503	DC721KB	No	QW
870	N015878	1	CHARGER7.2V-18V	DE9135		No	QW

C

