



## Parts List for DCS551B Type 1

Item Number	Part Number	Description	Qty Required
1	N401266	HOUSING ASSEMBLY	1
2	N401267	MOTOR & SHAFT ASSY	1
3	389461-00	COMP. SPRING	1
4	623263-00	COLLET LOCK	1
5	392448-00	COMP. SPRING	1
6	623315-00	COLLET GRIP	1
7	389458-00	COLL.GRP.COV.	1
8	330019-02	SCREW,PLASTITE	2
9	389244-00	1/4 COLLET	1
9	389243-00	1/8 COLLET	1
10	389245-00	COLLET NUT	1
11	330019-03	SCREW,PLASTITE	6
12	145312-00	PLUG,RUBBER	6
13	N401269	SWITCH & MODULE	1
14	N324203	SWITCH ACTUATOR	1
15	625759-00	BOOT	1
16	626734-00	EXT RET RING	1
17	389459-00	GUIDE	1
18	389460-00	GUIDE BASE	1
19	045687-00	STAR WASHER	1
20	396992-01	KNOB	1
21	N382916	RATING LABEL	1
22	N389197	IDENT LABEL	1
23	N388450	WARNING LABEL	1
856	391023-00	DRYWALL BIT	1
856	DW6601	GENERAL PURPOSE BIT	1
862	N261499	SOFT BAG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DCS551B Type 1

Item Number	Part Number	Description	Qty Required
866	DCB203	BATTERY PACK	2
871	DCB101	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.