



Parts List for DC330K Type 10

Item Number	Part Number	Description	Qty Required
1	586202-01SV	MOTOR ASSY.	1
2	603754-01	BRUSH BOX	2
3	152274-23	SWITCH KIT	1
4	329810-00	FAN	1
5	583069-00	ADAPTER PLATE	1
6	156179-01	SCREW,TAPTITE	3
7	330045-15	SCREW,M5X20	4
8	652425-00	LOCK-OFF BUTTON	1
10	490989-00	PINION	1
11	621367-00	LEADWIRE	1
12	621370-00	LEADWIRE	1
15	330065-07	SCREW	7
16	655339-00	CLAMSHELL SET	1
16	581437-00	CLAMSHELL SET	1
17	581269-00	GUARD	1
20	324006-00	SCREW	4
21	581577-00	CASTING	1
22	584627-00	PIN	1
23	581418-00	SPRING	1
24	589055-00	ACTUATOR	1
25	590336-00	GEARCASE COVER	1
26	581244-00	GASKET	1
27	330045-09	SCREW	2
30	330045-06	SCREW	2
31	582837-00	BOLT	1
32	N072135SV	BLADE CLAMP	1
33	582262-00	SEAL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DC330K Type 10

Item Number	Part Number	Description	Qty Required
34	582263-00	FELT SEAL	1
35	586646-00	SPRING,COMP.	1
36	582259-00	BEARING	1
37	581274-00	RECIP. SHAFT	1
38	582260-00	BEARING CARRIER	1
39	324006-00	SCREW	4
40	490329-00	BEARING	1
46	582261-00	CLAMP	1
47	582257-00	DRIVE ROLLER	1
48	571181-00	CLIP	1
49	582829-00	WASHER	2
50	479146-00	SCREW	1
51	330004-02	BEARING,NEEDLE	2
52	479403-00	CRANK KIT	1
53	589012-00	COUNTERWEIGHT	1
55	581435-00SV	GEAR ASSY.	1
56	581247-00	ACTUATOR	1
58	585113-00SV	GEARCASE ASSY	1
65	581255-00	LEVER	1
66	326467-00	DETENT	2
67	582830-00	BODY	1
68	582831-00	BAFFLE	1
70	589056-00	BRACKET	1
72	330041-29	PIN	1
73	584450-00	NOZZLE	1
74	330041-49	PIN	1
76	581257-01	LEVER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DC330K Type 10

Item Number	Part Number	Description	Qty Required
77	330003-95	BALL BEARING	2
78	584639-00	CLIP, SPRING	1
84	493248-00	LEVER	1
85	581263-00	SHOE	1
86	493248-00	LEVER	1
88	584686-00	PLUNGER	1
89	496996-00	CLAMP PLATE	1
90	582826-00	BOLT	1
91	582828-00	WASHER	1
92	582827-00	BOLT	1
94	581264-00	SOLE PLATE	1
95	389235-00	SCREW	4
96	581268-00	SOLE PLATE	1
100	402140-00	DEVICE,ANTI.SPL	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
816	587466-00	IDENT. LABEL	1
821	659509-00	NAMEPLATE	1
821	586842-03	NAMEPLATE	1
856	1004501-00	RIP FENCE	1
856	494873-00SV	BLADE PACK	1
856	648210-00	JIG SAW BLADE	1
861	N179861	KIT BOX	1
866	DC9180	18V BATTERY PACK	1
866	DC9096	BATTERY PACK	1
867	645221-00	BATTERY CAP	1
871	DC9310	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DC330K Type 10

Item Number	Part Number	Description	Qty Required
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.